



Specifications subject to change without notice

SPACER NUT

Spacer nut for installing latches in insulated or laminated doors. The nut is used in combination with housing of corresponding length.

The nut is supplied in two versions:

X: The threaded area located at the flange-end (see drawing). Use on long housings to speed up mounting. Clamps on to front panel only.

Y: The threaded part located at the open end (see drawing). Use on thick doors, insulated doors or similar. Clamps on to both sides of the double-sided door.

MATERIAL:

Zinc die-cast, zinc plated or stainless steel (304).

SPACER NUT FOR QUARTER TURN LATCHES

P/N	Thread Y	P/N	Thread X
291118	L=15,0 mm	291134	L=22,5 mm
291132	L=21,0 mm	291120	L=25,5 mm
291119	L=23,5 mm	291133	L=37,5 mm
291129	L=25,0 mm	291130	L=48,0 mm
291127	L=38,0 mm	291121	L=50,0 mm
291131	L=44,0 mm	293001	L=29,0 mm - SS (304)
291128	L=48,0 mm		
293028	L=50,0 mm - SS (304)		